

- Device classification: NON MEDICAL DEVICE
- ANSM registration number: NO
- GMDN code: NO

Applied rules: Non Medical Device article because they are not intended to be used for medical purposes on humans in terms of Article L5211-1 and R5211-1 of French code of public health.

<i>General description</i>	Head magnifying glasses	
<i>Attachments</i>	Yes	Photo, diagram
<i>Batch Reference</i>	No	
<i>Connected device</i>	No	
<i>Single use device</i>	No	
<i>Sterile device</i>	No	
<i>Sterilisation</i>	No	
<i>Autoclavable</i>	No	
<i>Cleaning</i>	Yes	With 70% alcohol.
<i>Unsuitable substance</i>	Products that attack ABS (Acrylonitrile butadiene styrene)	
<i>Component parts</i>	No	
<i>Material</i>	ABS (Acrylonitrile butadiene styrene)	
<i>Contains latex</i>	No	
<i>Contains Bisphenol A</i>	No	
<i>Labelling</i>	Yes	Name, reference, COMED, address, Batch, recycling, instruction for use.
<i>Packaging</i>	Yes	In a plastic bag and a cardboard box
<i>Special packaging</i>	No	
<i>Marking on medical device</i>	No	
<i>References</i>	32 930 00	32 930 05
<i>Designation</i>	Magnifying glasses	Magnifying glasses with lighting
<i>Dimensions L x W x H (mm)</i>	185x160x60	210x160x60
<i>Net weight (g) +- 1%</i>	112	163
<i>Colors</i>	Black	Black
<i>Magnifying power</i>	1 = 1,8 x 1 + 2 = 2,3 x	1 + 3 = 3,7 x 1 + 2 + 3 = 4,8 x
<i>Head measurement (cm)</i>	Between 52 and 62	
<i>Usage</i>	Allows more precise near vision.	
<i>Instruction for use</i>	Place the magnifying glass on the head by adjusting the holding band through the Velcro. Glasses already set gives a magnification of 1.8 x (1). By adding the two retractable lens magnification = 2.3 x (1 + 2). The combination of the two fixed lenses and the lens gives you a magnification of 3.7 x (1 + 3). Finally, when the three magnifiers are together, the magnification is 4.8 x (1 + 2 + 3).	
<i>Precautions for use</i>	This equipment is suitable for the occasional observation of small details. Do not use any product other than alcohol for cleaning, the glass may become blurred.	
<i>Recycling</i>	Yes	
<i>Recycling/Recovery</i>	Plastic bin	
<i>WEEE/REACH</i>	Yes (model with lighting)/NC	
<i>PVC/PHTHALATES</i>	No/No	
<i>Safety data</i>	R-Phrases = None Combination phrases = None	

The COMED company is not responsible for the placing on the market but acts only as a distributor.